

Features

- Fits atop the accessory ledge of the K-3760 and K-3761 Stages kitchen sinks.
- Comes included with the K-3760 and K-3761 Stages kitchen sinks.
- Versatile tray can either contain items or be flipped to act as a cutting board.
- Durable plastic construction.
- Dishwasher safe.

Recommended Products/Accessories

K-3760 under-mount single-bowl kitchen sink K-3761 under-mount single-bowl kitchen sink K-23723 Faucet cleaner



Codes/Standards None Applicable

KOHLER[®] One-Year Limited Warranty

See website for detailed warranty information.

Available Colors/Finishes

Color tiles intended for reference only.


Color Code Description

0 White



Stages[™] Flip Tray K-6231





Technical Information

All product dimensions are nominal. Material: Plastic

