


Item # : AF70JER
Assembly Instructions



Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com

Revised 02/2018


General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The two main types of hardware used to assemble this product are : screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.




VI. Power tools should not be used to assemble this product.





Hardware List


Α	Ø1/4"x30mm	Bolt	24 pcs
В	Ø1/4"x12mm	Bolt	37 pcs
С	Ø4x35mm	Screw	8 pcs
D		Bracket	1 pc
E	Ø16	Washer	1 pc
F	Ø4x30mm	Screw	1 pc
G		Anchor	1 pc
Н	M 4	Hex Key	1 pc




Philips head screwdriver required for assembly (not included)

The hardware quantities listed above are required for proper assembly.


Some extra hardware may also have been included.




Attach part (4) to part (5) using bolt (B) and Hex Key (H). Repeat this step twice.



Attach part (2) to part (4) using bolt (B) with Hex Key (H) and screw (C) with a screwdriver. Attach part (3) to part (5) using bolt (B) with Hex Key (H) and screw (C) with a screwdriver. Repeat this step twice.




Step 4




Attach part (6,7) to part (1) using bolt (B) with Hex Key (H).


Attach part (7) to part (1) using bolt (B) with Hex Key (H). Repeat this step five times.




Attach part (4,5) to part (6,7) using bolt (A) with Hex Key (H).



Attach part (4,5) to part (6,7) using bolt (A) with Hex Key (H).




Step 9



Secure furniture to anchor (G) in wall using washer (E) and screw (F) with a screwdriver.

Step 10



Final Assembly