## ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provided).

<b>)</b> .	PART LIST		
9	ITEM	DESCRIPTION	QTY
	Α	CHAIR	1PC
	В	FRONT LEG	2 PCS
	С	FRONT LEG SUPPORT (METAL)	1 PC
	D	BACK LEG	2 PCS
	Е	BACK LEG SUPPORT	1 PC
	F	SIDE RAIL	2 PCS
			•

	HARDWARE LIST		
ITEM	DESCRIPTION	QTY	
1	JCBB BOLT M8 x 60mm	8 PCS	
2	WOOD SCREW M4 x 20mm	2 PCS	
3	WOOD SCREW M4 x 45mm	6 PCS	
4	WOOD SCREW M3.5 x 12mm	12 PCS	
5	WOOD SCREW M3.5 x 16mm	12 PCS	
6	M8 FLAT WASHER	8 PCS	
7	M8 SPRING WASHER	8 PCS	
8	M5 ALLEN KEY (BALL SHAPE)	1 PC	
9	5005 2 HOLE L BRACKET (BLACK)	4 PCS	
10	5003 2 HOLE L BRACKET (BLACK)	8 PCS	







