

LUMINOSA

Model #LT1008, LT1009


Model #EFG1011-2

Model #LT1010, LT1011

Model #EFG8012A


Use and Care Guide INTERIOR FLUSHMOUNT

PACKAGE CONTENTS



PLANNING INSTALLATION


Read all instructions before assembly. Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



INSTALLATION


1. Attaching the mounting strap to the outlet box

- Screw the mounting screws (GG) into the mounting strap (CC).
- Mount the mounting strap (CC) to the outlet box using the two outlet box screws (BB).



2. Connecting the electrical wires


- Wrap the ground wire from the fixture around the ground screw (FF) on the mounting strap (CC). Connect the ground wire from the fixture to the ground wire from the outlet box (JJ).
- Cover the connection using the wire connector (AA).
- Insert the white (neutral) wire from the outlet box (JJ) into the quick wire connector (AA) connected to the white wire from the fixture.
- Insert the black (live) wire from the outlet box (JJ) into the quick wire connector (AA) connected to the black wire from the fixture.
- Wrap the connections with electrical tape for a more secure connection.



INSTALLATION (Continued)


3. Securing the canopy to the outlet box

- Place the Canopy (HH) over the Outlet Box (JJ). Allow the heads of the Mounting Screws (GG) to come out through the large ends of the keyholes (MM) on the Canopy (HH).
- Twist the Canopy (HH) until the heads of the Mounting Screws (BB) slide into the narrow ends of the keyholes (MM).
- Tighten the Mounting Screws (BB) to secure the Canopy (HH).



4. Attaching the shade

- Place the shade (II) and the cover (PP) over the nipple (DD).
- Screw the finial (QQ) onto the nipple (DD) to secure.



Note: Fixture may use one or two bulbs depending on model.

Warranty

WHAT IS COVERED

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of five (5) years from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling.

WHAT IS NOT COVERED

This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear.

The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.

Safety Information



WARNING: Carefully read and understand the information given in this manual before beginning the assembly and installation. Failure to do so could lead to electric shock, fire or other injuries which could be hazardous or even fatal.



WARNING: Be sure the electricity to the wires you are working on is shut off. Either remove the fuse or turn the circuit off.


CAUTION: Risk of Fire. Do not remove insulation. The insulation is located on both sides of the canopy. It is required by UL and included to protect the light fixture from the heat caused by the light bulb(s). The insulation should not be removed.

NOTICE: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Email our customer service at
luminosaservice@gmail.com
or call 1-877-399-5251


GUÍA DE USO Y MANTENIMIENTO PLAFÓN DE PARA INTERIORES

CONTENIDO DEL PAQUETE



PLANIFICACIÓN DE LA INSTALACIÓN


Lee todas las instrucciones antes de ensamblar. Antes de comenzar la instalación o de quitar la instalación anterior, desconecte la alimentación apagando el interruptor del circuito o quitando el fusible en la caja de fusible. Para evitar dañar el artículo, ensámblalo sobre una superficie suave, no abrasiva, como por ejemplo una alfombra o cartón.



Instalación


1. Acoplar la correa de montaje a la caja de salida

- Atornille los tornillos de montaje (GG) en la correa de montaje (CC).
- Monte la correa de montaje (CC) a la caja de salida usando los dos tornillos de la caja de salida (BB).



2. Conectar los cables eléctricos


- Envuelva el cable de toma de tierra de la instalación alrededor del tornillo de toma de tierra (FF) que hay en la correa de montaje (CC). Conecte el cable de toma de tierra de la instalación al cable de toma de tierra de la caja de salida (JJ).
- Cubra la conexión usando el cable conector (AA).
- Inserte el cable blanco (neutral) desde el toma corriente al cable de conexión rápida (AA) conectado al cable blanco desde el accesorio.
- Inserte el cable negro (vivo) desde el toma corriente al cable de conexión rápida (AA) conectado al cable negro desde el accesorio.
- Envuelva las conexiones con cinta aislante para una conexión más segura.



Instalación (continuación)


3. Asegurar el dosel a la caja de salida

- Colocar el Dosel (HH) sobre la Caja de Salida (JJ). Deje que las cabezas de los Tornillos de Montaje (GG) se salgan a través de los extremos grandes de los agujeros que hay en el Dosel (HH).
- Retorcer el Dosel (HH) hasta que las cabezas de los Tornillos de Montaje (GG) deslicen en los extremos estrechos de los agujeros.
- Atornillar los Tornillos de Montaje (GG) para fijar el Dosel (HH).



4. Acoplar la pantalla

- Coloque la pantalla (II) y la cubierta (PP) sobre la enterrosca (DD).
- Atornille el embellecedor (QQ) en la enterrosca (DD) para asegurar la pantalla (II).



Nota: Luminaria puede utilizar uno o dos bombillas dependiendo de modelo

Garantía

LO QUE ESTA CUBIERTO

El fabricante garantiza que esta lámpara no presentará defectos materiales o de fabricación por un período de cinco (5) años a partir de la fecha de compra. Esta garantía es válida sólo para el comprador original y sólo cubre los productos en uso y funciones normales. Si se descubre algún defecto en este producto, la única obligación y solución exclusiva del fabricante, a criterio del mismo, será reparar o reemplazar el producto siempre y cuando el defecto no sea resultado de un mal uso, abuso, accidente, modificaciones, alteraciones, negligencia o manejo indebido.

LO QUE (NO) ESTA CUBIERTO

Esta garantía no cubre ningún producto instalado, configurado o usado incorrectamente sin seguir las instrucciones adjuntas al producto. Esta garantía no cubre fallas del producto a consecuencia de un accidente, mal uso, abuso, negligencia, modificaciones o instalaciones defectuosas, o cualquier otra falla no relacionada con defectos materiales o de fabricación. Esta garantía no se aplica al acabado de ninguna parte del producto, como por ejemplo el de la superficie, ni al deterioro por condiciones ambientales, ya que eso se considera un desgaste normal.

El fabricante no garantiza y rechaza especialmente cualquier garantía, expresa o implícita, de idoneidad para un propósito en particular, distinta de la garantía indicada aquí. El fabricante se exime específicamente de cualquier obligación y no es responsable por daños o pérdidas directas o indirectas, lo que incluye cualquier costo de mano de obra o gastos relacionados con el reemplazo o reparación de dicho producto.

Información de Seguridad



ADVERTENCIA: Lea cuidadosamente y entienda la información dada en este manual antes de empezar el proceso de ensamble e instalación. Si falla en hacerlo, puede ocasionar un choque eléctrico, incendio u otros daños que pueden ser perjudiciales o fatales.



ADVERTENCIA: Asegúrese de que la electricidad A que llega a los cables con los que se encuentra trabajando estén apagados. Remueva el fusible o apague el interruptor.

PRECAUCIÓN: Riesgo de incendio. No quitar el aislamiento. El aislamiento se encuentra en ambos lados de la cubierta. Es requerido por UL y se incluye para proteger el dispositivo de luz del calor causado por la(s) bombilla(s). El aislamiento no debe ser eliminado.

ANUNCIO: Cualquier cambio o modificación que no se encuentre expresamente aprobada por el proveedor responsable del cumplimiento puede revocar la autorización del usuario a utilizar el equipo.

Correo electrónico a nuestro servicio al cliente
luminoservice@gmail.com
o call 1-877-399-5251