








DS-829-

ASSEMBLY INSTRUCTION

Ax1 	Ex1 		
Bx1 	Fx4 		
Cx1 	Gx4 		
Dx1  PLEASE REMOVE BLACK GAP FROM GAS LIFT	Hx1 		
Ix1 	Jx8 		