


DESK






ASSEMBLY INSTRUCTION

HARDWARE LIST

A 14 PCS	 M6x40mm	B 6 PCS	 M6x12mm	C 17 PCS	 M6x28mm	D 1 PC	 4mm	E 16 PCS	 φ7x40mm
F 2 PCS	 M4x40mm	G 4 PCS	 φ13x1.0mm	H 2 PCS		I 2 PCS		J 2 PCS	

PARTS LIST




①  2PCS	②  2PCS	③  1PCS	④  1PCS	⑤  1PCS	⑥  1PCS
⑦  1PCS	⑧  1PCS	⑨  1PCS	⑩  1PCS	⑪  1PCS	⑫  1PCS
⑬  2PCS	⑭  2PCS				



ASSEMBLY STEPS



STEP 1.

Fix parts 3, 4 and 5 to part 2 using screws (A), (B) and allen key (D), as shown.



STEP 2.



Fix parts 7, 8 and 9 to part 2 using screws (A), (B) and allen key, as shown.



ASSEMBLY STEPS

STEP 3.


Fix part 6 to parts 3, 4 and 5 and connecting parts 7, 8 and 9 using screws (A) and (B) with allen key, as shown.
Fix part 10 to parts 8 and 9 using screws (A) and allen key, as shown.



STEP 4.






Fix parts 13 and 14 to part 2 using screws (E) and allen key, as shown.



ASSEMBLY STEPS




STEP 5.

Fix part 1 to parts 13 and 14 using screws (E) and allen key, as shown.



STEP 6.



Fix parts 13 and 14 to part 2 using screws (E) and allen key, as shown.



ASSEMBLY STEPS


STEP 7.

Fix part 1 to parts 13 and 14 using screws (E) and allen key, as shown.



STEP 8.



Fix parts 11 and 12 to assembled unit using screws (C) and allen key, as shown.



ASSEMBLY STEPS

STEP 9.

Fix wall straps (H) to assembled unit using screws (I) and washers (G), as shown.



STEP 10.

For extra stability, you must fix your Desk to the wall using hardware (F, G and J), as shown. Screws (F) are fixed through wall straps and washers (G) and into the wall plugs (J). Should you choose not to affix the product to the wall, serious injury may be caused if the product tips over.

