

ASSEMBLY INSTRUCTION

Shoe Storage





REPLACEMENT PARTS

Please do not contact the company purchased from as we can help you faster. Order replacement parts and hardware at " www.boltonfurniture.com "




- . Use of power tool to assemble this product will invalidate any claim and damage this product making it unsafe !!!
- . Please assemble on a clean soft surface to avoid damage.






www.boltonfurniture.com




Identifying the hardware-Identify the hardware using the illustrations below





2 of 9


ANLO0333 Shoe Storage


03/03/2022


















www.boltonfurniture.com







03/03/2022



Tighten the Screw marked (II) to fasten hinge. The door may need to be adjusted so that all the spaces between the door and the unit sides are equal. To adjust, follow instructions:


- 1. Side adjustment 4 mm

 To move the door towards the side panel, loosen screw (I) and tighten screw (II) .

 To move the door away from the side panel, loosen screw (II) and tighten screw (I) .
- 2. Depth adjustment 4 mm Loosen screw (II) (just one turn), adjust door to desired position, re-tighten screw .
- 3. Height adjustment Loosen screw (L) , adjust door to desired position, re-tighten screw .

"S" Anti-Tip A QUADA O4 C Plastic wall bracket B 4x35 Screw O4 D Nylon strap 140mm O2

Secure to Stud behind Wallboard



www.boltonfurniture.com