

Palmetto Craft

QUALITY AMISH-MADE FURNITURE

Complete assembly videos can be found on palmettocraft.com

SWING ASSEMBLY INSTRUCTIONS

1) Place pre-assembled seat on a level surface. Align 3 pre-drilled holes on seat with the 3 pre-drilled holes on the pre-assembled back supports (**see figure 1**).

2) **Secure center support** with 2 ¼" bolt, washer and nut. Secure the end supports with 3 ½" bolts, washers, and nuts (**see figure 2**). **Hand tighten.**

3) Attach chain assembly to swing by inserting 3 ½" bolt through the last link on shortest chain length through a washer into pre-drilled hole in back end of arm rest, then through pre-drilled hole in bench back. Add second washer and nut (**see Chain Assembly diagram and figure 3**). Repeat to attach medium chain length to front end of arm rest, then through front of seat (**see figure 4**). Repeat to attach 2nd chain assembly to arm rest on other side of swing.

4) **Wrench tighten all nuts and bolts.**

HARDWARE INCLUDED:

- (1) 2 ¼" bolt
- (6) 3 ½" bolts
- (11) washers
- (7) Nuts
- (2) chain assembly

Important Note:


Your furniture has been kiln-dried and ready to stain, paint or water seal to help preserve it and keep it looking nice longer. Please note, exposure of all woods to outdoor elements can cause fading, warping, cracking, shrinking or expansion. The manufacturer and distributor of this product cannot be held responsible for damage or changes caused by natural weathering.



Figure 1



Figure 2



Chain Assembly



Figure 3



Figure 4



Finished Swing

Note on Chain Assembly:

Chain assembly has 3 distinct lengths

Long - for hanging swing
Medium - Attaches to front of arm rest
Short - Attaches to back of arm rest