




DESCRIPTION

WF300021




A




(2 pcs)

B




(2 pcs)

C




(1 pcs)


CARTON CONTENT:
WF300021:



A x 2




B x 2




C x 1

STEP 1




STEP 2

Loosen the safety latch and pull the chair leg back




STEP 3

Secure the chair legs with the available hooks





STEP 4

Loosen the safety latch and pull the chair leg forward




STEP 5


Pull the top of the lounge forward and secure it with the lounge's body. Slide the bolt into available position and secure it



STEP 6



STEP 7



STEP 8

