
OPOLAR LF150 Series 6 Inch USB Desk Fan **User Manual**



Always here to help you

Visit www.opolar.com to register the product to extend its warranty to

For any questions or help, please send an email to support@opolar.com

Thanks for choosing us!

Congratulations on your purchase and thanks for your support to OPOLAR! Please kindly read the user manual before using the product and keep it for future reference.

Specifications

| Size(Inch) | 7.5 * 6.7 * 2.5 |
|-----------------------|--|
| Material | ABS Plastic Metal |
| Power Supply | DC5V USB |
| Power Consumption | 1W-6.75W |
| Revolution Per Minute | Speed 1 - 1446RPM Speed 2 - 1870RPM Speed 3 - 2109RPM Super wind - 2310RPM (Long press to enter this mode, it failed, please use 2A power supply |
| Motor Rotate Speed | Speed 13.3-3.4 m/s Speed 24.2-4.3 m/s Speed 34.6-4.7 m/s Super wind5.2-5.3 m/s |
| Power Cord Length | 4.9 feet |
| Noise | ≤55dB |
| Weight(lb) | 0.72lb |

Note

- * Long press the button to enter the highest setting (Super wind).
- * The highest setting ONLY works on 2A output current.

Precautions

- Children must not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- The appliance must be placed on a firm flat surface.
- Do not cover when in use.
- Do not use water to clean the unit. Cleaning should be carried out with a clean, dry brush or cloth.
- Do not insert any object between the grilles and the fan blades.
 Do not use the fan in excessively hot or humid environments.

Cleaning and Maintenance

- 1. Always unplug the unit from the power supply before servicing or cleaning.
- 2. Rotate the front cover to take it down.
- 3. Clean the fan blade and its frame with a clean and dry cloth. Do not use water to clean the fan.
- 4. Rotate the front cover to put it back.
- 5. When the fan is not in use, store it in a dry area away from sunlight and heat.