


Thank you for buying 'Cook house - knife utensils storage'

Installation instructions.

Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

Knife utensils storage is supplied with screws and wall plugs suitable for a stone or brick wall. For other wall types (eg. hollow plasterboard) alternative fixings will be required. If in doubt, consult a qualified person.




Parts:

- ① Wooden storage box x1

Fixings:

- Ⓐ Wall screws 50mm x2
- Ⓑ Wall plugs 40mm x2



Fitting Instructions:

You will need a power drill, masonry drill bits, medium crosshead screwdriver, a spirit level and pencil to install this product. Ensure the wall surface is of suitable strength and construction before hanging. If in doubt consult a qualified professional.

Carefully measure the position of the holes on the back of the storage box. Mark the drill hole positions for the wall plugs on the wall using a spirit level to check alignment. Drill holes to depth of 45mm and push in wall plugs so they are flush.

*Helpful hint: To accurately drill wall holes, first use a smaller drill bit. Then change to the larger drill bit size and re-drill.

Fix wall screws securely leaving screw heads protruding 4mm from the wall.

Guide the keyhole hanging slots onto the wall screws and check it's securely fixed to the wall before use. Adjust the depth of the wall screws if necessary.

Cleaning:

Wipe using a damp cloth with mild soap solution; do not use substances containing abrasives.

Warnings:

Make sure knives and utensils are dry before storing.
Max load 2kg