


# ASSEMBLY INSTRUCTIONS

## DINING TABLE






### NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

## PARTS IDENTIFICATION

<p><b>A</b> Quantity: 1</p>  <p>Table Top</p>	<p><b>B</b> Quantity: 4</p>  <p>Table Legs</p>	
---	---	--

## HARDWARE IDENTIFICATION - in Carton A

<p><b>1</b> Quantity: 8</p>  <p>JCBB Bolt m8 x 80mm</p>	<p><b>2</b> Quantity: 8</p>  <p>Spring Washer m8</p>	<p><b>3</b> Quantity: 8</p>  <p>Flat Washer m8</p>	<p><b>4</b> Quantity: 1</p>  <p>Allen Key m5</p>
--	---	---	--

