

FRASER HILL FARM®

58-In. Dancing Baking Santa and Mrs. Claus



Who's helping Santa and dancing along the way? Mrs. Claus, that's who! Our Dancing Baking Mrs. Claus and Santa Claus, from Fraser Hill Farm, will dance right into your heart as they help you greet your family, guests, or customers. Standing 3 feet tall and holding Christmas cookies, they will be a delightful addition to your holiday decor in any home, office, or shop.

When motion is detected, they will move their arms and sway their bodies to Jingle Bells. Dressed in a festive white apron over a red velvet dress with a coordinating mob-cap, Mrs. Claus' warm smile will fill you and yours with holiday cheer. Place her in a window display, near the fireplace, or next to the Christmas tree and watch as she entertains everyone with glee. For even more holiday fun, pair her with our Dancing Baking Santa Claus to complete the look!

- Animated indoor holiday decor by Fraser Hill Farm
- When motion is detected, they move their arms and sway their bodies to music (approx. 34 seconds)
- *Motion sensor is triggered from a distance of approximately 1.5 to 5 feet*
- *Jingle Bells* can be heard through the music speakers

Model Number	UPC	Height	Width	Description
FAMC058-2RD1-AA	192487239032	58 in.	15 in.	Dancing Baking Mrs. Claus
FSC058-2RD2-AA	192487338520	58 in.	15 in.	Dancing Baking Santa Claus