


# ASSEMBLY INSTRUCTION

ITEM# 366-75-008 POKER TABLE BASE

ITEM# 366-75-009 POKER TABLE TOP

\*\*\*Caution: Please read all instructions carefully before starting the assembly process.



NO	Hardware List		Q'ty
D		Allen Wrench	1
E		Bolt	4
F		Lock Washer	4
G		Flat Washer	4





Diagram 1



1. Assemble the table on a flat, soft surface to prevent from scratching the table finish.
2. Attach the pedestal to the table using 4 Bolt (E), 4 Lock washer (F) and 4 Flat washer (G) as shown in Diagram 1 .
3. Tighten all the bolts securely. .

**Note:** To remove the felt top, look for hidden hand-grips (H) along the edges of the felt top and lift top off. When replacing the felt top, make sure the velcro in the center of the table is aligned

**Caution:** Do not over tighten.

*Cleaning Instruction: Clean finished parts with a mild dishwashing liquid and water solution on a damp cloth. Polish the finish with soft cloth and an industry recognized furniture polish.*