

# **ASSEMBLY INSTRUCTIONS**

**Description:** Ventura Lounge

## Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

## Pre-assembly:


- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

#### Parts List

Item	Description		QTY
P1	Back Frame		1
P2	Seat cushion	$\Diamond$	1
P3	Right Arm	K	1
P4	Left Arm	K	1
P5	Front Stretcher		1

#### Hardware List

Item	Description		QTY
H1	Bolts Ø1/4"*1-1/2"	0	10
H2	Lock Washers 1/4"	0	10
Н3	Big flat washers 1/4" (19mm)	0	4
H4	Small flat washers 1/4" (12mm)	0	6
H5	Allen Wrench 1/4"		1
H6	Wooden Plugs	0	6





#### **DISCLAIMER:**


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

# **Assembly Procedures:**


Step 1. Assemble the lounge on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach seat cushion (P2) to back frame (P1) as shown below. Loosely tighten the bolts with Allen wrench (H5).








- Step 3.
- 1) Insert the dowels on the ends of front stretcher (P5), then attach the front stretcher (P5) between right arm (P3) and left arm (P4).
- 2) Loosely tighten right arm (P3) to the front stretcher (P5), seat cushion (P2) and back frame (P1) as shown below.




Page 2 of 3

Step 4. Loosely attach the assembled left arm (P4) to front stretchers (P5).



Step 5.

- 1) Make sure the assembled lounge is level and securely tighten all the bolts with Allen wrench (H5).
- 2) Attach wooden plugs (H6) to each exposed bolt holes, tighten with rubber hammer to knock the wooden plug till its tighten. **Note:** use a soft cloth between the wooden plug and hammer to prevent damage to wooden plug finish.
- 3) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



**ADDITIONAL NOTE ABOUT SAFETY:** 

**BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.** 

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase