

ASSEMBLY INSTRUCTION

SUNPAN



Sunpan Product Name: **FUENTES SIDEBOARD**

Please visit our website www.sunpan.com for more great products

For assembly questions please call **1-800-787-1019 (or +1-416-736-0094)** outside North America or email to info@sunpan.com

PARTS LIST			
Before you begin, please layout all parts and ensure you have the correct count.			
PARTS	DESCRIPTION	QUANTITY	ILLUSTRATION
A	Sideboard	1	
B	Removable Shelf Panels	2	
C	Shelf Holders	8	
D	Round-head Screws M4X15MM	8	
E	Tipping Restraint Sets	2	<div>TIPPING RESTRAINT</div>
F	Phillips Screwdriver (Not Included)	1	

ASSEMBLY INSTRUCTIONS

STEPS	DESCRIPTION	ILLUSTRATION
1	<p>Open the door and remove all the Shelf panels (B) from the Sideboard (A). Place the sideboard in desired location. Check the leveling, and adjust the levelers underneath the legs if necessary.</p> <p>At the desired height of the shelf panels, insert the metal shelf holders (C) into the bore holes on the inside surface of the side panels. Set the shelf panels on the shelf holders. Install screws (D) to fix the shelf panels to the metal shelf holders.</p>	
2	<p>Attach two of the mounting brackets near the top edge of the back side of the furniture by inserting the shorter screws.</p>	

3

Determine the final position of the dresser. Mark locations on the wall approximately 2" below the brackets mounted to the back of the furniture.

Drill a shorter hole into the wall stud. If wall stud is not available, drill a hole into the wall and insert plastic anchor. Gently tap the anchor until the flange is flush with the wall.

Attach the second set of brackets by inserting the longer screw through the bracket and into the wall.


Place the item so that the brackets on the back edge and in the wall are in line.

Thread one end of the nylon restraint strap down through each bracket. Bring both ends together and slide the beaded end until it snap locks into the keyhole slot.

To double lock; return the beaded end back through the keyholes as shown.

Check to make sure the straps are securely laced and locked to the brackets.

Repeat all of the previous steps to attach on the other side.



ASSEMBLY TIPS:

Please check parts and hardware before assembling. Follow each instruction step by step.

Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.

Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.

Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.

Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.