

ASSEMBLY AND INSTALLATION INSTRUCTIONS

PD35454/PD35459

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps

1. Attach the nipple-1 to the mounting strap, and then secure with a washer and a hex nut.
2. Attach the mounting strap to the ceiling box by using two mounting screws.
3. Secure the loop to the nipple-2 tightly.
4. Choose a certain length of the chain you need, and then weave the fixture wire and the grounding wire through the chain links. Connect one end of the chain with the loop by using the loop lock.
5. Secure the top loop to the nipple-1.
6. Thread the fixture wire and grounding wire through the collar, top loop, canopy, nipple-1 and mounting strap in order.
7. Connect the other end of the chain link to the top loop by using the loop lock.
8. Make wire connections with wire nuts:
 - The smooth wire (marked) from fixture to the black wire from power source.
 - The ridged wire (unmarked) from fixture to the white wire from power source.
 - Attach the grounding wire and house grounding wire to the mounting strap with a green grounding screw. Carefully tuck wires back into the ceiling box.
9. Attach the canopy to the mounting strap by inserting the top loop, and secure with the collar.
10. Screw the nipple-3 into the couple, and secure with the hex nut. Then attach the cap upward to the fixture, and secure with the finial.
11. Attach the candle covers to the sockets.
12. Install bulbs. (**Please do not exceed the maximum capacity which, is recommended on the package.**)
13. Turn on the power at fuse or circuit box.

