




MANHATTAN
COMFORT

CT013



Ver. 05032024




STOP!


Before beginning the assembly process, ensure all boxes and parts have been delivered.

FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



TOOLS REQUIRED



SUPPORT SITE





View our assembly video online:
WWW.MANHATTANCOMFORT.COM



Stuck? Question? We are here to help.
tel: **908-888-0818**
e-mail: help@manhattancomfort.com



PARTS SUPPLIED FOR ASSEMBLY



NUMBER 1- SMALL TOP PANEL X3
NUMBER 2- RIGHT SIDE PANEL X3
NUMBER 3- LEFT SIDE PANEL X3
NUMBER 4- BACK PANEL X3
NUMBER 5- MIDDLE FOOT X1
NUMBER 6- RIGHT FOOT X1
NUMBER 7- LEFT FOOT X1
NUMBER 8- TOP PANEL X1
NUMBER 9- POOF X1
Total 9 Pcs. + Hardware Box



A X 34 PCS



B X 30 PCS



C X 18 PCS



R X 28 PCS




Z X 2 PCS

Step 1

Note: Skipping any steps could lead to improper assembly and damages.
Do not tighten the bolts before finishing all steps.

NUMBER 1: SMALL TOP PANEL X3




3x

THREE TIMES




DO NOT USE ELECTRIC TOOL!

Hardware



Step 2 NUMBER 2: RIGHT SIDE PANEL X3




3x

THREE TIMES



DO NOT USE ELECTRIC TOOL!


Hardware



Step 3 NUMBER 3: LEFT SIDE PANEL X3



USE SCREWDRIVER!




3x

THREE TIMES



DO NOT USE ELECTRIC TOOL!


Hardware



Step 4 NUMBER 4: BACK PANEL X3



USE SCREWDRIVER!



3x

THREE TIMES




DO NOT USE ELECTRIC TOOL!

Hardware



Step 5 NUMBER 5: MIDDLE FOOT X1




DO NOT USE ELECTRIC TOOL!



USE SCREWDRIVER!


Hardware



A X 2 PCS

Z X 2 PCS

Step 6 NUMBER 6: RIGHT FOOT X1



DO NOT USE ELECTRIC TOOL!




USE SCREWDRIVER!

Hardware



A X 4 PCS

Step 7 NUMBER 7: LEFT FOOT X1



USE SCREWDRIVER!




DO NOT USE ELECTRIC TOOL!

Hardware



A X 4 PCS

Step 8 NUMBER 8: TOP PANEL X1



DO NOT USE ELECTRIC TOOL!


Hardware



B X 6 PCS

C X 6 PCS


Step 9



3x

THREE TIMES


Step 10



3x

THREE TIMES


Step 11




3x

THREE TIMES


Step 12



Step 13



Step 14





MANHATTAN
COMFORT

WARRANTY POLICY

All Manhattan Comfort furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons. This warranty is valid in the United States of America and Canada.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.



319 Ridge Rd. Dayton, NJ 08810
908-888-0818