


ASSEMBLY INSTRUCTIONS



Tools needed (not included): **Level, Drill, Screwdriver, Ruler or Tape measure, Hammer, Pen**
Please see assembly instruction video: woodekdesign.com/maintenance-overview



1. Measure and mark the mounting keyholes.
2. Drill suitable holes into the marked locations and insert wall plugs into the drilled holes.
3. Insert screws into the plug leaving suitable space.
4. Hang item to wall matching slots on back of hook to wall screws.

PS!

Please note that product is treated with oil and can rub off on clothing when opening the packaging. This is due to natural differences of the wood as various parts of an item will absorb the oil differently.

GENERAL SAFETY WARNINGS!

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Execute all steps fixation described in this assembly guide.
- Never allow children to climb or hang on furniture.
- Do not set heavy objects on the top of this product.
- It is the users responsibility to ensure the proper use and installation of this product. The manufacturer accepts no responsibility for failure due to incorrect or inappropriate installation.

Hardware components included:

2x anchors with screws*

Warning! This bag contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should not permanently affixed to the furniture.

*** Please note, if these anchors are not suitable for your wall, consult an installation professional to identify the proper anchors.**