



H O O K E R
— F U R N I T U R E —

ASSEMBLY INSTRUCTION


Item: 1600-55466-DKW-Entertainment Console 66in

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A		GLASS PAD	Φ12*2	12pcs



Step 1

Step 2

Adjustable
Leveler