

Outdoor Furniture and Décor Care Guide

A. Deco Ropes

Our Deco Ropes are crafted from intricate fiber strings reinforced with filament yarns, ensuring a robust and resilient structure. Whether it's our Deco Tex. Rope or Deco Polyolefin rope, both variants boast exceptional durability. Engineered to resist stains and simplify cleaning, our ropes offer effortless maintenance.

1. Cleaning Instructions:

- a. **Non-greasy Marks:** For minor stains, spot clean with a solution of half a spoonful of standard washing powder/liquid (Non-Bleach) diluted in a cup of warm water. Blot the affected area with a cloth or sponge soaked in this solution. After stain removal, rinse the spot with clean water to eliminate any residue. Avoid using stain removers.
- b. **Oil or Grease Spots:** Stubborn stains like butter, oil, or lipstick can be easily tackled using the same spot cleaning method as described above.
- c. **Avoid High-Pressure Cleaning:** Refrain from using high-pressure water spray equipment on your furniture. Instead, opt for a gentle rinse with a general gardening hose if necessary.

2. Features:

- a. Our Deco Ropes are engineered to withstand sunlight, saltiness, sunscreen cream, abrasion, sweat, and stains for years to come, ensuring worry-free maintenance.

B. (Mesh) Fabrics:

We exclusively utilize premium quality mesh, Sunbrella, Acrylic, and Olefin fabrics known for their durability. All fabrics undergo rigorous testing adhering to ROHS & REACH standards.

1. Cleaning Instructions:

- a. Cleaning our fabrics is a breeze – simply use lukewarm water and a cloth, occasionally supplemented with a mild detergent. Thanks to their design, dirt and water cannot penetrate the fibers, allowing for easy maintenance with a simple wipe.

C. Storage:

When storing your furniture indoors or under a cover, ensure that the fabrics and inner cushion fillings are completely dry to prevent mold or fungus growth.

D. Aluminum and Steel Parts:

Clean aluminum and steel parts of the furniture with water, mild soap, and a sponge. Rinse thoroughly to remove any residue after cleaning.

E. Teak:

Teak furniture can be cleaned with a mixture of lukewarm water and soda, using a soft brush for gentle scrubbing. Over time, teak develops a charming silver/grey patina, which does not compromise its durability or weather resistance. To maintain the original color, various products like Teak protector, Teak oil, and Teak repairs are available in the market.

1. Storage Tip: When covering your teak furniture, ensure the cover is not airtight to allow for ventilation, preventing mold or fungus growth that could damage the product permanently.