


HOOKER[®]

— FURNITURE —

ASSEMBLY INSTRUCTION

Item#: 5820-75200T - 84 Rectangle Dining Table Top
 5820-75200B - 84 Rectangle Dining Table Base

**** Please make sure you have all parts indicated below prior to assembly.
 This table is heavy and can best be assembled with the help of two or more people.**

NO	HARDWARE LIST		Q'TY
A		FLAT WASHER	12
B		LOCK WASHER	12
C		$\frac{5}{16}$ "*35MM ALLEN BOLT	8
D		ALLEN WRENCH	1
E		$\frac{5}{16}$ "*100MM ALLEN BOLT	4





Diagram 1




Diagram 2

Assembly steps:

1. Place two side frames upside down.
2. Attach the ends of stretcher (H) to base on left side frame (F) and right side frame (G) by using bolts (E), lock washers (B) and flat washers (A), tighten all bolts securely with allen wrench (D) (See Diagram 1).

3. Place table top (L) upside down on a soft surface to prevent it from being scratched. Put whole base onto top to make sure all pre-drilled holes are in alignment, well insert bolts (C), lock washers (B) and flat washers (A), tighten bolts by turning with allen wrench (D) in clockwise direction (See Diagram 2).

4. Turn table upright.

Instruction for table leaves:

1. There are latches at the bottom of table top, turn off the latches as shown in Diagram 2.

2. Pull out table top as the arrow direction shown in Diagram 3.

3. Place table leaves between and push table tops together.

4. Turn on latches. (see Diagram 2)

5. Take opposite actions to remove table leaves.




Diagram 3

Cleaning Instruction: Clean finished parts with a damp cloth using a mild dishwashing liquid and water solution. Polish the finish with soft cloth and an industry recognized furniture polish.