














BT-134-A

PARTS

 (1)X1	 (7)X1
 (2)X1	 (8)X5
 (3)X1(L)X1(R)	 (9)X12
 (4)X1	 (10)X4
 (5)X1	 (11)X8
 (6)X1	 (12)X1

ASSEMBLY INSTRUCTION

 1	 2
 3	 4
 5	 6



A-134-V

