



Step 4 Parts list F1023-BAF-MB / F1023-BAF-BG



NO.	Description	NO.	Description
1	Handle cup	18	Gasket
2	Set Screw	19	Outlet pipe
3	Handle Lever	20	Tube
4	Wear-resistant sheet	21	Pedestal
5	Cup	22	Gasket
6	Pedestal	23	Bolt sleeve
7	Gasket	24	Ring
8	Spool	25	Gasket
9	Spool body	26	Nuts
10	Ring	27	Y-pipe
11	Gasket	28	Pipe
12	Nuts	29	O-Ring
13	Set Screw	30	Wear-resistant sheet
14	O-Ring	31	Rocking core
15	Protective cover	32	Casp
16	Bushing	33	O-Ring
17	Bubbler	34	Screw




Two Handles Bathroom Faucet

product is cUPC, NSF-61, NSF 372, AB1953, CEC, WaterSense certified by IAPMO R&T. ASME A112.18.1/CSA B125.1




The tools might be applied to the following places:



Step 1 Faucet installation

- 1.1 Shut off water supply.
- 1.2 Flush water connection at home to make sure no debris is stuck in the line.
- 1.3 Connect flexible hose to brass pipe for hot and cold handles assembles.
- 2.1 Place handle and spout assembles in position on the countertop.
- 2.2 From under the sink, put rubber washer, metal ring and brass nut onto each threaded pin. Tighten nuts.
- 2.3 Use a screwdriver to tighten each screw.






- 1. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute.
- 2. Check all connections at arrows for leaks, re-tighten it if necessary.



BUT DON'T OVERTIGHTEN



Step 3 Cleaning and care

Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- 2 Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.

- 3 Attach ends of guick connection hose to hot and cold assembles.
- 4.Connect the flexible hoses to water supply valve (not included) and copper tubes, and tighten it with adjustable wrench.**DON'TOVER TIGHTEN!**

Caution: make sure connect the hot and cold flexible hose to supply valves correctly.



Warning: The supply valves are not included, please purchase them in plumbshop