



Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion, within the one-year warranty period. Proof of purchase, with the date of purchase as well as photos of the defective merchandise, must be provided.

If you have any questions, comments or concerns please feel free to contact us by phone at: **888-881-4668**. You may also contact us by email: [customerservice@serenityhealth.com](mailto:customerservice@serenityhealth.com), or via our webpage at: [www.serenityhealth.com/contact-us/](http://www.serenityhealth.com/contact-us/)

GSI-311



#### Warning

- Do not tip fountain as fuel can spill out and cause fire or serious injury.
- For outdoor use only.
- Fuel not included. Use torch fuel or bio ethanol fuel. Use of any other fuel will void your warranty.
- Failure to follow warnings and instructions may result in serious injury or destruction of property.
- Keep out of reach of children or pets.
- Do not leave flame unattended.
- Do not move fountain while burning. Hot while in use.
- To prevent burns and other injuries, snuff flame and allow to cool completely before handling.
- Refill flammable liquid before use, and only refill when flame area is cold. Wait at least 30 minutes before refilling or cleaning.
- Keep clothing, hair, and body parts away from flame; may cause serious injury or burns.
- DO NOT place fountain under covered shelter or umbrella, or near other combustibles, such as, but not limited to: wood structures, clothing, or dry vegetation.
- Use in a well-ventilated area.
- Do not spill flame fuel into water portion of fountain as that may cause damage to the fountain, pump, or destruction of property.
- Keep fountain out of reach of children.
- Use proper power source as indicated on water pump label.
- Keep electrical cords away from all heat sources. Do not place electrical cords in high temperatures. Check water level at pump location regularly, to avoid damage the pump must be fully submerged.

## PARTS:

- A. Basin -1pc
- B. Pump and Transformer -1pc
- C. Fountain body-1pc
- D. Torch Top- 1pc
- E. Pebbles-1 bag

## ASSEMBLY:

1. Connect the pump with the hose and lower into the basin.
2. Place the torch top onto the fountain body.
3. Place pebbles on top of the basin, and spread out.
4. Fill with water, and then plug fountain into electrical outlet.

## Troubleshooting:

Pump operates but no water flow: Make sure pump is fully submerged in water. If there is still no water flow, please turn pump on then off several times.

Water speed: Adjust the switch control located on the pump housing.

Noise from pump/Fountain: Make sure pump is fully submerged in water.

