CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

 * Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening

Part List and Hardware List



Model # SEA8014

Product Dimensions : 18.5"W x 27.5"D x 39"H

DESCRIPTION	PICTURE	QUANTITY
Seat		1X
Back Rest	1	1X
Front leg-1		1X
Front leg-2		1X
Bolt 8 X 60 mm	()mmmm)	6X
Flat Washer	0	6X
Spanner	5	1X
Black Fabric		1X
	Seat Back Rest Front leg-1 Front leg-2 Bolt 8 X 60 mm Flat Washer Spanner	SeatBack RestFront leg-1Front leg-2Bolt 8 X 60 mmFlat WasherSpanner



Weight Capacity: 300 lbs

WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS

A

WARNING

The legs and hardware are located underneath the chair in the zipper compartment.

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Spanner

