#### **CARE AND MAINTENANCE**

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

#### **NOTICE**

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

## Part List and Hardware List

А	Table top	and the same of th	1X
В	Leg		2X
С	Metal bar		1X
H1	Allen bolt ( long)	<i>Ф</i> иш Ф8∗35ММL	4X
H2	Allen bolt (short)	Ф8*20MML	1X
НЗ	Cap nut	Ф 10 ММ	2X
H4	Spanner	<b>&gt;</b> Ф10 ММ	1X
H5	Allen key		1X



Model# AMH4127A

Product Dimensions: 25"W x 25""DX 24"H




## **PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Spanner & Allen key



# Step

Upside down the table top (A) and attach the leg (B) to the table top (A). Use the allen key (H4) to tighten the bolt (H1). Attach the metal bar (C) to the leg (B) and to the table top (A). Use the allen key (H4) to tighten the bolt (H2) and use the span to tighten the cap nut (H3)