



Motor to receiver electrical connections: Connect the blue wire from the fan to blue wire from the receiver. Connect the white wire from the fan to the white wire from the receiver. Connect the gray wire from the fan to the gray wire from the receiver. Connect the red wire from the fan to the red wire from the receiver. Connect the pink wire from the fan to the pink wire from the receiver. Secure the wire connections with the plastic wire connecting nuts provided.