


## Parts Included


Wench



## CSA / UL SAFETY REQUIREMENTS

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

- ☐ Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.



- ☐ Consult a qualified electrician if you have any electrical questions or need to replace the driver.

## ASSEMBLY INSTRUCTIONS

# LEIPZIG


# 429110108



## Care Instructions

Arnsberg suggest using only micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

## Mounting Instructions



## ASSEMBLY INSTRUCTIONS FOR **LEIPZIG** 429110108

### Assembly Instructions

1. Carefully unpack and lay out the parts as shown in the illustration.
2. Screw in the Top Tube (#4) onto Middle Tube (#3) while pulling Cord through bottom.
3. Screw the Middle Tube (#3) to the Bottom Tube (2) while pulling Cord through bottom.
4. Insert the Bottom Tube (#2) to the Base (#1), while pulling Cord through bottom.
5. Place the Lamp Plate(#7) onto the Top tube(#4) and secure it.
6. Place the Glass(#6) over the Lamp Plate(#7) ,put the screws and tighten the screws to secure the Glass(#6).