



BT-9025H-2 PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(6)X5 
(2)X1 	(7)X4 
(3)X1 	(8)X4 
(4)X1 	(9)X(1) 
(5)X1 	

