

## CARE AND MAINTENANCE






Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening


## Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Back		1X
B	Seat		1X
H1	Flat Washer	 Ø16-Ø6	4X
H2	Allen Bolt	 M6*12mm	4X
H3	Allen key	 M4	1X



Model# FOX2013

Product Dimensions:18" WX22-1/4"DX 34-3/4"H




## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



### Step 1

Turn the chair frame upsidedown.

Use Allen wrench H3 to tighten flat washer H1 into bolt H2 to the seat A.