




PARTS AND HARDWARE


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



ASSEMBLY INSTRUCTIONS


Do not fully tighten bolts until assembly is complete

- 1 Hand thread the full threaded stud (D) into the bottom of the backrest. Insert Back rest into seat base assembly.




G2
F
E
I

- 2 From under the seat base attach the backrest assembly to the seat base using washer (G) lock washer (F) and nut (H). Tighten using provided t wrench (J).



- 3** Attach the wooden leg to the Chair seat base using bolt (e) lock washer (f) and washer (g). Tighten using provided allen key (I).



- 4** Enjoy your new Maybo accent chair - Note from time to time you may need to retighten the legs and back assembly



Model: BIS604WT
Name: Maybo accent chair
Batch No: BSHL-BW



WARNING: This product may contain small components, please ensure they are kept away from small children.