

Before beginning the assembly of the product , make sure all parts are present . Compare the parts with package contents list and hardware contents list . If any parts are missing or damaged,do not attempt to assemble the product . Tool required for assembly (included): Allen key





Step 1: attach left side (E) to back (B) with support 1 (A) and support 2 (F) as shown on picture, using bolt (H1) and tighten with the Allen key (H4).

Then continue with left side (E) with same way.

Make sure tighten all bolt (H1) before continue step 2

Step 2: put the seat (D) inside chair and using screw (H2) as shown on picture, tighten with screwdriver.

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum .Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
Α	Support 1		1 X
В	Back		1 X
С	Seat		1 X
D	Right side		1 X
E	Left side		1 X
F	Suport 2		2 X
H 1	Allen Bolt	(a) (b) (c) (d) (d) (d) (d) (d) (d) (d) (d) (d) (d	8 X
H 2	Screw	‰ M4x35	2 X
Н3	Bolt extra	@	1 X
H 4	Allen Key		1 X



MODEL: PAT 6721

Product Dimension :24.41"W x24.41"D x34.65"H


Weight capacity: 300 lbs

Warning: Do not stand on the chair Warning: Do not torque bolts / screws











PREPARATION

Before beginning the assembly of the product, make sure all parts are present. Compare the parts with the package contents list and hardware contents list. If any parts are missing or damaged, do not attempt to assemble the product. Tool required for assembly (included): Wrench.





Step 1: turn the table top (A). Then attach the 4 legs (B) as shown on the picture.

Step 2: use the wrench (C) to tighten all bolts as shown on the picture.

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when it is not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

Please make sure that you have all parts indicated before you begin assembly of this item.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Table top		1 X
В	Leg		4 X
С	Wrench		1 X
D	Lid		1 X



MODEL# PAT6721

Product Dimension: 35.43"W x 35.43"D x 29.53"H

Weight capacity: 40 lbs.

Warning: Do not stand on the table Warning: Do not torque bolts / screws







