

1

2

3

4

A x1	B x1
C x2	D Quant. MESSENGER x2
E Quant. MESSENGER x6	F x1
G Quant. MESSENGER x6	H x1
I x1	J x1
K Quant. MESSENGER x4	L Quant. MESSENGER x7

HL-0004-HR-GG

HEADREST ASSEMBLE INSTRUCTION

