

WARNING

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

CARE AND MAINTENANCE


Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE & IMPORTANT SAFETY INSTRUCTIONS

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- *The external flexible cable or cord of this lamp cannot be replaced;
If the cord is damaged, the lamp shall be destroyed

**This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. this plug will fit in a polarized outlet only one way. if the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. do not attempt to disregard this safety feature.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Top shelf		1X	I	screw cover		4X
B	Middle shelf		2X	J	Shade		1X
C	Base shelf		1X	K	Bulb		1X
D	Socket board		1X	L	Screwdriver		1X
E	Top Square tube		4X	M	Cork		4X
F	Middle Square tube		12X	N	Wool Mat		4X
G	screws		8X	O	Wire clip		3X
H	thread-pipe		12X				

JONATHAN Y

Model# JYL8506A


Product Dimensions: 10.25"Lx 10.25"W x 63.5"H



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 6 minutes.

**PLEASE USE ON/OFF TYPE "A" BULB MAX 60-WATT OR CFL BULB MAX 13-WATT OR LED BULB MAX 9-WATT
THERE IS LED 9.5-WATT BULB IN THE BOX**





Step 1
Carefully remove all parts from the box and remove all plastic coverings.

Refer to Diagram 1: insert 4pcs Middle Square tube(F1) onto the Base shelf (C) with the screws(G) by the Screwdriver(L) and place the Wool Mat (N) to cover the screw holes.

Refer to Diagram 2: insert 4pcs Middle Square tube(F1) into the 4pcs Middle Square tube(F2) by the thread-pipe(H) through the Middle shelf(B1).

Insert 4pcs Middle Square tube(F2) into the 4pcs Middle Square tube(F3) by the thread-pipe(H) through the Middle shelf(B2).


ENJOY YOUR LAMP



Step 2
Insert 4pcs Middle Square tube(F3) into the 4pcs Top Square tube(E) by the thread-pipe(H) through the Socket board(D)

Insert Top shelf(A) onto the Top Square tube(E) with the screws(G) by the Screwdriver(L), and place the screw cover (I) to cover the screw holes.

Step 3
Insert the 4pcs Cork(M) into the Socket board(D) holes
Put the the Shade (J) onto the Socket board(D)
Insert the bulb(K) into the Socket board(D).



Step 3
Put the light on a level surface to check if everything is stable.

Insert 3pcs Wire Clip (O) onto the Square tube(F1-F2-F3)

Insert the wire into the Wire Clip (O), Secure the wire and prevent tripping

