

















Model 3425 Assembly Instructions

Parts Listing

- | | |
|---|---|
| A

5PCS | B

1PC |
| C

4PCS | D

2PCS |
| E

2PCS | F

1PC |
| G

6PCS | H

4PCS |
| I

1PC | J

1PC |
| K

1PC | L

1PC |
| M

1PC | N

1PC |



WL-3425-GG



ASSEMBLY NOTES:

During assembly, hand tighten screws only. When all screws are in place, you may then tighten all screws completely.

CAUTION: 1. Do not use this chair as a step ladder.

2. Check for loose screws and tighten them anytime.

Made and printed in Taiwan. 2010.03.03