


SIMPLI™
H O M E

Wynden+Hall™
HOME DECOR
brooklyn + max™

BURLINGTON / PORTLAND / BERKSHIRE

COFFEE TABLE

MODEL # 3AXCBUR-001





DO NOT RETURN

**FOR REPLACEMENT PARTS OR OTHER
INQUIRIES PLEASE CONTACT US AT:**

simpli-home.com/customer-support

**PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR
INSTRUCTION BOOKLET**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. We do not recommend the use of power tools for assembly as this could damage the unit. Only use manual tools.

May require 2 people for ease of assembly.

CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.

Do not use ammonia-based cleaning products, as they will damage the finish.


Do not leave liquids or damp cloths on this furniture.

To avoid dulling of the finish, do not place furniture in direct sunlight.

Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.


PARTS DESCRIPTION

A




SIDE
QTY 2

B




TOP
QTY 1

C




BOTTOM SHELF
QTY 1

D




DIVIDER
QTY 1 PAIR

E




DRAWER FRONT
QTY 2

F




DRAWER SIDE
QTY 2 PAIRS

G




DRAWER BACK
QTY 2

H



DRAWER BOTTOM
QTY 2

I




BACK PANEL
QTY 1

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 5 pm EST)


HARDWARE DESCRIPTION

1




ALLEN KEY SCREW
M6 X 30 mm
QTY 27

2



CAM LOCK PIN
CAM LOCK
QTY 14 SETS

3




ALLEN KEY
QTY 1

4




WOOD DOWEL
Ø8 X 30mm
QTY 4

5




HANDLE
QTY 4 SETS




Required -
Flathead screwdriver
Phillips screwdriver
Not Included


NEED HELP? For help with assembly or if you are missing a part,
Please call customer service at 1-866-518-0120 ext. 262 (9 am to 5 pm EST)



STEP 1




NOTE: The screwdriver is not included in the hardware pack.




1. Attach 4 Cam Lock Pins (2) to back of Drawer Front (E) .
2. Align Cam Lock Pins with pre-drilled holes and attach Drawer Sides (F) .
3. Insert 2 Cam Lock (2) into pre-drilled holes on each Drawer Side (F) .
4. Use flathead screwdriver to secure Cam Locks.

STEP 2





1. Slide Drawer Bottom (H) firmly into slots on Drawer Side (F) and Drawer Front (E).

STEP 3



1. Align Drawer Back ⑥ with Drawer Bottom ④ and press firmly into slot .
2. Attach back using 2 Allen Key Screws ① through pre-drilled holes on each side.
3. Use Allen key ③ to tighten. Do not over tighten.


STEP 4




NOTE: The screwdriver is not included in the hardware pack.

1. Use Phillips screwdriver to attach Handle ⑤ to Drawer Front ⑤.


Repeat Step 1-4 for the second drawer .



STEP 5




NOTE: The screwdriver is not included in the hardware pack.




1. Attach 3 Cam Lock Pins ② to each Side ① using guide holes.
2. Align Cam Lock Pins with pre-drilled holes on Bottom Shelf ③.
3. Insert 6 Cam Locks ② into pre-drilled holes on Bottom Shelf ③.
4. Use flathead screwdriver secure Cam Locks.
5. Insert 6 Allen Key Screws ① into pre-drilled holes through the bottom of 2 Dividers ④ into Bottom Shelf ③ (3 screws / each Divider).
6. Use Allen Key ⑤ to tighten. Do not over-tighten.

STEP 6






1. Place front facing of table assembly on flat surface.
2. Insert 4 Dowels ④ into edges of Back ①.
3. Align pre-drilled holes on Bottom Shelf ③ with 2 Dowels ④ in Back ①.
4. Insert Allen Key Screws ① into pre-drilled holes through center of side frame of Bottom Shelf ③ into Back ①.
5. Use Allen Key ③ to tighten. Do not over tighten .

STEP 7



1. Align pre-drilled holes on Top ② with 2 Dowels ④ in Back ①.
2. Insert 12 Allen Key Screws ① into pre-drilled holes on Sides ③ and Dividers ④ into Top ② (3 Screws / each Side and Divider).
3. Use Allen Key ③ to tighten. Do not over tighten .


STEP 8



NOTE: The screwdriver is not included in the hardware pack.

1. Use a Phillips screwdriver to attach Handles ⑤ to Back ①.

STEP 9



1. Insert assembled drawers into glides on assembled table.



WARRANTY

Thank you for purchasing a **Simpli Home – Wyndenhall – Brooklyn + Max** product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line at 1-866-518-0120 ext. 262 from 9 am to 5 pm, Monday to Friday, Eastern Standard Time or by email at simpli-home.com/customer-support.

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.

PLEASE NOTE: This item is hand-crafted and hand-finished with utmost care. As such, variations and imperfections should be expected and should be welcomed as the natural beauty of the wood.



Question, problems, missing parts?

Before returning please email Customer Support at
simpli-home.com/customer-support
or call

Customer Service at 1-866-518-0120 ext. 262
Monday to Friday between 9 am – 5 pm EST

For more information visit us on our website
www.simpli-home.com

Like us on facebook
www.facebook.com/simplihomefurnishings

**ENTER
TO WIN**

**Upload an image of our furniture in your
home with a short review to our
facebook page and have a chance to**

**Win your choice of any one of
Simpli Home furniture pieces
Free!!!**

www.facebook.com/simplihomefurnishings

(draws monthly – shipping included)

(vanities not included)

