






Mirror




Vanity Front







Vanity Back



TOOLS FOR ASSEMBLY




MIRROR INSTALLATION




DRAWER REMOVAL & INSTALLATION


REMOVAL



INSTALLATION




1 Install legs



2 Remove drawer



3 Install cabinet

IMPORTANT: Consult an expert for the proper screws/bolts to use when attaching to various wall constructions. Screws provided do not attach to all wall construction types.




4

Install top panel




P-TRAP AND POP-UP INSTALLATION INSTRUCTIONS




POP-UP INSTALLATION

FOR SINKS WITHOUT OVERFLOW



OR


FOR SINKS WITH OVERFLOW



P-TRAP INSTALLATION

1

Install tail pipe (G)



2

Install p-trap (J)

