

XU-LECTERN-ADJ-GC Assembly Instructions

Part Drawing	Description	Qty
P-1	Lower Receiver	1 EA
P-2	Short Foot Assembly	2 EA
P-3	Upper Insert	1 EA
P-4	Top Platform	1 EA
P-5	Pencil Stop	1 EA


Part Drawing	Description	Qty
A	Flat Head Screw	5 EA
B	Wood Screw	6 EA
C	Interior Threaded Post	5 EA
D	Plastic Knob	1 EA
E	Leveling Feet	4 EA
F	Allen Wrench	1 EA

Tools required: 1 Phillips Screwdriver

READ THROUGH INSTRUCTIONS FROM BEGINNING TO END BEFORE STARTING TO ASSEMBLE UNIT.


To Assemble:

1. Identify and Separate all the Parts and Hardware.
2. Place the Top Platform (P-4) with the insert nuts facing up. Attach Upper Insert (P-3) using 4 Wood Screws (B) as shown in illustration # 1. (Tighten Wood Screws using Phillips Screwdriver)
3. Attach Pencil Stop (P-5) to the Top Platform (P-4) using 2 Wood screws (B). (Tighten Wood Screws using Phillips Screwdriver)




Do not use unless all screws are tight.
At least every six months, check all screws to be sure they are tight.
If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.

Illustration # 3
Final Assembly



4. Attach 2 each Short Foot Assemblies (P-2) to the Lower Receiver (P-1) using 5 Flat Head screws (A) and 5 Interior Threaded Posts (C) shown in Illustration # 2. Tighten Screws using Allen Wrench (F).
5. Attach 4 each Leveling Feet (E) to the Lower Receiver (P-1) and 2 Short Foot Assemblies (P-2) as shown in illustration # 2.

Illustration # 2 - Base Assembly



6. Slide the Top Assembly into the Base Assembly and Secure at desired height using Plastic Knob (D).

