CARE AND MAINTENANCE

Always use felt pads under allarticles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from sratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item

* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Top-L		1X
В	Leg-L		2X
С	Bar-L		1X
D	Top-S		1X
E	Leg-S		2X
F	Bar-S		1X
H1	hex nut	0	12X
H2	Wrench		1X
H3	Allen bolt	∯########### M8X20mm	4X
H4	Allen key		1X
H5	Rubber cap		4X

SAFAVIEH FURNITURE

Model# FOX4267

Product Dimensions:L:52-1/3"WX17"DX33-1/2"H

S:48-2/5"WX17"DX31-1/2"H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 15 minutes.

Tools Required for Assembly (included): Allen Key




Step 1

Attach the legs(B) to the top (A),using hex nuts(H1) Tighten with wrench(H2)




Step 4 Cover the holes with rubber caps(H5)




Step 2


Attach the legs(B) to the top (A),using hex nuts(H1) Tighten with wrench(H2)




Step 3

Attach the bar (C) to the legs(B), using allen bolts(H3) Tighten with Allen key(H4)








Setp 6

Attach the legs(E) to the top (D), using hex nuts(H1) Tighten with wrench(H2)





 Setp 1
 Setp 8

 Attach the bar (F) to the legs(E),using allen bolts(H3)
 Cover the holes with rubber caps(H5)

 Tighten with Allen key(H4)
 Fighten with Allen key(H4)