


SHOWER ENCLOSURE SINGLE SLIDING&SIDE PANEL INSTALLATION INSTRUCTIONS

320048+36P-MB/320056+36P-MB
320060+36P-MB/320064+36P-MB
320068+36P-MB





IMPORTANT-Please

read and follow all warnings and instructions before using this product. Injury can result from improper use. Save this documents.



WARNING
Tempered Glass, please
don't hit the corners and
the surrounding, otherwise
the glass will burst.



Ø0.24"



Ø0.125"



● General Information

Please inspect the product immediately upon receipt for transit damage, missing packs/parts or manufacturing fault. Damage reported later cannot be accepted. Please handle the product with care avoiding knocks and shock loading to all sides and edges of the glass.

Notes: Safety glass can not be re-worked.

Please read these instructions carefully before start of installation.

Special care should be taken when drilling walls to avoid hidden pipes or electrical cables.


Note: This product is heavy and may require two people to install.

Aftercare instructions

After use, your shower should be cleaned with soap and water. This is particularly important in hard water districts where insoluble lime salts may be deposited and allowed to build up. Cleaners of a gritty or abrasive nature should not be used. Care should be taken to avoid contact with strong chemicals such as organic solvents and strippers.

Glass cleaners can be used but with caution, if in doubt contact the manufacturer of the cleaner in question.



Please keep these instructions for aftercare and customer service details.




- [1] 1xSupport Bar.
- [2] 1xBottom Threshold.
- [3] 1xFixed Panel.
- [4] 1xDoor Panel.
- [5] 1xClosing Gasket.
- [6A] 1xSide Gasket (Longer).
- [6B] 1xSide Gasket (Shorter).
- [7] 1xHandle Set.
- [8] 4xTop Rollers.
- [9] 2xSupport Bar Wall Brackets.
- [10] 2xAnti-collision Components.
- [11] 2xFasteners.
- [12] 1xBottom Slider A.

- [13] 1xBottom Slider B.
- [14] 1xWall Plug.
- [15] 1xScrew St4x25.
- [16] 1xWall Post.
- [17] 1xSide Panel.
- [18] 1xWall Post Cover.
- [19A] 1xSide Panel Fastener (L).
- [20] 1xU Gasket.
- [21] 1xSupport Bar Fastener.
- [22] 2xScrews ST4x16.
- [23] 3xScrews ST4x30.
- [14] 4xWall Plugs.
- [15] 1xScrew ST4x25.

● **Box Contents-1:** 320048-SS-MB/320056-SS-MB/320060-SS-MB/ 320064-SS-MB/320068-SS-MB/320160-SS-MB

1xInstallation Instruction.	➔	
[1] 1xSupport Bar.	➔	
[2] 1xBottom Threshold.	➔	
[3] 1xFixed Panel.	➔	
[4] 1xDoor Panel.	➔	
[5] 1xClosing Gasket.	➔	
[6A] 1xSide Gasket (Longer). [6B] 1xSide Gasket (Shorter).	➔	
[7] 1xHandle Set.	➔	
[8] 4xTop Rollers.	➔	
[9] 2xSupport Bar Wall Brackets.	➔	
[10] 2xAnti-collision Components.	➔	
[11] 2xFasteners.	➔	
[12] 1xBottom Slider A. [13] 1xBottom Slider B.	➔	
[14] 1xWall Plug. [15] 1xScrew ST4x25.	➔	

● Box Contents-2: 320036-SP-MB

1xInstallation Instruction.	➔	
[16] 1xWall Post.	➔	
[17] 1xInserted Gasket.	➔	
[18] 1xSide Panel.	➔	
[19] 1xWall Post Cover.	➔	
[20A] 1xSide Panel Fastener (L). [20B] 1xSide Panel Fastener (R). [21] 1xU Gasket.	➔	
[22] 1xSupport Bar Fastener.	➔	
[23] 2xScrews ST4x16. [24] 3xScrews ST4x30.	➔	
[14] 4xWall Plugs. [15] 1xScrew ST4x25.	➔	








● Assembly



4


01







Size	L1
48"(1219mm)	44.4"-48.3"(1127-1228mm)
56"(1422mm)	52.4"-56.3"(1330-1431mm)
60"(1524mm)	56.4"-60.3"(1431-1533mm)
64"(1626mm)	60.4"-64.3"(1533-1635mm)
68"(1727mm)	64.4"-68.3"(1635-1736mm)

Size	L2
36"(914mm)	35-35.8"(889-909mm)













0





3x





06

LH





RH






08

LH



RH



VINNOVA










FASHION BATHROOM LIFE

09


LH



RH



10



11


LH



2x

[8]


[4]






RH





[4]














- Do not use the shower enclosure for at least 24 hours in order to allow the silicone sealant to cure fully.