


CONVENIENCE CONCEPTS

Convenience Concepts

Trestle Desk

090107



ASSEMBLY INSTRUCTIONS

We have designed our furniture with you , the customer in mind . Our clear , easy to follow , step by step instructions will guide you through the project from start to finish . Feel confident that this will be a fun and rewarding project . The final product will be a quality piece of furniture that will go together smoothly and give years of enjoyment .


















Please do not return to the store

Broken or missing parts?






Need help with assembly?

If you have any questions just call 1-800-468-6447 or email us at parts@convenience-concepts.com

Hardware List



A 	F 	G 
Cam dowel (4pcs)	Hole sticker (12pcs)	Allen wrench (1pc)
B 	Part List	
Wood dowel (8pcs)		
C 		
Long Screw & Inserted Nut (12pcs)	Middle Shelf (1pc)	
D 		
Screw (6pcs)	Shelf Supports (4pcs)	
E 		
Glue (1pc)	Support Rail (1pc)	
		
	Left Frame (1pc)	Middle Frame (1pc)
		
		Right Frame (1pc)

Assembling the unit with camlocks and wood dowels.

				
Insert camlock, camlock must face bolt hole	Gently screw cam dowel into the threaded anchor	Lightly glue one end of wood dowel and tap into hole.	Lightly glue dowel and connect to second panel by inserting dowels into holes	Gently screw the cam clockwise into locked position. Do not overtighten.

step1



1. Attach Wooden dowels(B) and Cambolts(A) to Middle Shelf(2).
2. Insert Camlocks(A) into holes in Shelf Supports(4). Camlock arrow must face bolt hole.
3. Connect Shelf Supports (4) to Middle Shelf(2). Gently tighten camlocks.



*Refer to page 2 for dowel assembly

step2

1. Attach Wooden dowels(B) and Cambolts(A) to Bottom Shelf(3).
2. Insert Camlocks(A) into holes in Shelf Supports(4) and Camlock arrow must face bolt hole.
3. Connect Shelf Supports (4) to Bottom Shelf(3). Gently tighten camlocks.



step3

1. Insert Nuts into Middle Shelf(2) and Bottom Shelf(3) and make sure Nut hole faces to bolt hole.
(as seen in Diagram #1)
2. Carefully connect Left Frame(6) and Middle Frame(7) to Shelves (2) and (3). (Long Screw (G) goes through the Frame. Line up holes and insert screws.)
- Tighten Long Screws (G).






Diagram #1




step4

1. Place Desktop on carpet or soft surface.
2. Connect the assembly and Right Frame (8) to Desktop (1).
- Tighten Screws (D).



step5

1. Insert Nuts into Support Rail (5) and make sure Nut hole faces to bolt hole.
2. Carefully connect Support Rail (5) to Middle Frame (7) and Right Frame (8). (Long Screw (C) goes through the Frame. Line up holes and insert screws.)
- Tighten Long Screws (C).



step6

1. Carefully turn the desk.
2. Place hole stickers (F) over screw holes.
- Enjoy.

