W Series Presentation Row

Installation Instructions for WS-PR-1C & WS-PR models

Parts List

(1) Presentation Row Rack
 (13" [331mm] or
 39" [991mm] wide)

Required Tools

- Phillips Head Screw Driver
- Level
- Pencil

- (2) Plastic Couplers
- (4 or 8) Mounting Hole Caps
- (2 or 4) Spiral Drywall Anchors
- Tape Measure
 Power Drill
- 1/2" (12mm) drill bit

- (4 or 8) Screws
- (2 or 4) Toggle Bolts
- 1/16" (2mm) drill bit

Fasteners We recommend the following fasteners for these surfaces:

- Drywall: Use included toggle bolts and Spiral anchors
- Wood/stud (must be 1/2" (13mm) thick): Use included wood screws
- Concrete, Brick or Stucco: 3/16" x 1-1/4" masonry screw or #8 x 1-1/4" screw with appropriate size expanding concrete anchor
- VintageView W Frames (FCF-xx): Each Frame comes with self-drilling screws to attach Presentation Row



IMPORTANT NOTES:

• The W Series Presentation Row is designed to fit directly above or below one column (WS-PR-1C) or three columns (WS-PR) of W Series Wine Racks.

• When installing above W Series Wine Racks, it is recommended to install the Presentation Row first, as this will simplify the installation of the racks below and is necessary to allow Racks to couple side-to-side. Additionally, it is strongly recommended that in places where the racks will line up with each other, the end plugs are removed and/or replaced with couplers prior to installation of the Presentation Rows, for ease of access.













1. MARK MOUNTING HOLES

Position the rack on the wall where it is to be installed and use a level to ensure the rack is perfectly horizontal (Figure A). Using a pencil, mark all eight (8) mounting hole locations (four [4] for 1C models). Set the rack aside.

2. PREP SURFACE FOR ANCHORS

Using the 1/16" (2mm) bit, drill a pilot hole in the center of the marked hole locations. If a marked hole location is over a stud or the surface is wood (1/2" thick or greater) drill the pilot hole only and skip to step 3B. For drywall, use the 1/2" bit to enlarge the top mounting holes for the toggle bolt. Then, using a Philips Head Screwdriver, insert four (4) Spiral Drywall Anchors (two [2] for 1C models) into the lower row of mounting hole locations (Figure B).

3. HANG THE RACK for Drywall

Remove the expanding nuts from the toggle bolts and insert the bolts through the top four (4) mounting holes (two [2] for 1C model). Thread the expanding nuts back onto the bolts until the tip of the bolt is slightly protruding from the nut with the wings positioned so they will fold toward the head of the bolt (Figure C). Align the folded wings of the expanding nuts with the holes in the wall and gently push them through the wall, ensuring that both wings of the nut expand on the back side of the wall. When all toggle bolts are in place, gently tighten them using a screwdriver.

Insert four (4) Screws (two [2] for 1C models) into lower mounting holes and gentle screw into Spiral Drywall Anchors.

Check that the Rack is level and fully tighten all Toggle Bolts and Screws.

for Wood

Fasten the Rack through the mounting holes using the provided Screws. (Figure D)







4. INSERT MOUNTING HOLE CAPS

With the Rack fastened to the wall, simply press the provided mounting hole caps into the 1/2'' holes in the face of the Rack to cover the mounting hardware (Figure E).

5. ADD WINE

Only the good stuff.

Installing to W Series Frame

Place the rack against a W Series Frame in the position where it is to be installed and ensure that it is horizontal using a level. To secure the rack, use the Self Drilling Screws provided with the Frame and fasten the rack through each of the 8 mounting holes.

Note: If installing a full Presentation Row (3 columns wide), the W Series Frames need to be spaced using 13" to properly align with the legs of the Rack (Figure F).

Maintenance and Care:

Like every VintageView product, the W Series Presentation is backed by a lifetime warranty. They should be regularly checked for tightness. Should any piece to be found to be loose, tighten until secure. If the face of the wall surface shows signs of breakage, discontinue use immediately until the wall may be adequately repaired. W Series products may be cleaned with a damp cloth and mild dish soap — abrasive pads or steel wool should NOT be used as they will damage the finished surfaces of the parts.

Figure F

Need more help? Visit VintageView.com

13'

