ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL# BD01748F Full Size Bed


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Separate, identify, and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of the part(s) needed.

*** Do not fully tighten screws until fully assembled ***

| COMPONENT PARTS | | | | |
|-----------------|------------------------|------|-----------|--|
| DECERPTION | PART N | IAME | Q'TY(PCS) | |
| 1 | НВ | | 1pc | |
| 2 | FB | | 1pc | |
| 3 | Left HB Leg | | 1pc | |
| 4 | Right HB Leg | | 1pc | |
| 5 | Right FB Leg | | 1pc | |
| 6 | Left FB Leg | | 1pc | |
| 7 | Right Bed Tube | | 2pcs | |
| 8 | Left Bed Tube | | 2pcs | |
| 9 | Inner connection panel | | 2pcs | |

| 10 | Outer Connection Panel | 2pcs |
|-----|------------------------|------|
| 11) | Side Bed Board | 2pcs |
| 12 | Bed Board | 1pc |
| 13 | Support Tube | 2pcs |
| 14 | Decorative Board | 2pcs |

| HA | HARDWARE REQUIRED: | | |
|----------|--------------------|--------------------------|--|
| A |) | Bolt 1/4"x5/8" - 20pcs | |
| B | | Bolt 1/4"x1-3/8" - 14pcs | |
| © | | Bolt 1/4"x1-5/8" - 4pcs | |
| D | | Bolt 1/4"x3" - 4pcs | |
| E | (1) (1) | Bolt 5/16"x5/8" - 16pcs | |
| F | | Nut M6x27 - 4pcs | |
| G | | Allen Wrench M4 - 2pcs | |
| Θ | | Allen Wrench M5 - 1pc | |
| | (a) | Bolt 1/4"x1-1/8" - 4pcs | |




Attention:


^{***}Mattreses not included.

^{***}Some number parts listed on the instruction sheet may not be in parts bag as they may already be assemble. Carefully check parts and packing materials prior to odering replacements.

How to Assemble:



How to Assemble:



How to Assemble:

