




ASSEMBLY INSTRUCTIONS

2Door FC



Please provide the following information when contacting for parts or questions: the name of the company you purchased from, the tracking number of the original package, and the original order date.

We offer free replacements for 1 year (purchase verification required). This replacement policy does not cover used/previously returned product or products sold by unauthorized third party vendors.

ASSEMBLY INSTRUCTIONS-IMPORTANT


Carefully unpack & identify each component before attempting to assemble. Refer to parts list. Please take care when assembling the unit and always set the parts on a clean, soft surface. If you require any assistance with assembly, parts, please call the company you place order with or please email to: service@elegantfhf.net

INSTRUCCIONES PARA ARMAR-IMPORANT:


Desempaque cuidadosamente e identifique cada componente antes de tartar de empezar su ensambladura. Verifique la lista de partes. Por favor tenga cuidado cuando arme la unidad y siempre coloque las piezas sobre una superficie plana, suave y limpia. Si necesita ayuda con el armado, envíe un correo electzórico a service@elegantfhf.net

DIRECTIVES DE MONTAGE-IMPORTANT:





Avant de commencer l' assemblage, déballez délicatement toutes les pièces et repérez-les sur la liste des pièces. Procédez avec soins durant l' assemblage et posez toujours les pièces sur une surface proper, douce et lisse. sie vouo plait e-mail á service@elegantfhf.net



COMPONENTS

PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
A		TOP PANEL	1PC	F		BACK PANEL	2PCS
B		LEFT SIDE PANEL	1PC	G		PLASTIC BAR	1PC
C		RIGHT SIDE PANEL	1PC	H		LEFT D00R	1PC
D		ADJUSTABLE SHELF	2PCS	I		RIGHT D00R	1PC
E		BOTTOM PANEL	1PC				

HARDWARE & TOOLS

PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
1	 ø15*12	CAM LOCK	8PCS	8	 ø3*12 D=7	SCREW	16PCS
2		CAM BOLT	8PCS	10	 ø4*25	SCREW	2PCS
3	 ø8*30	WOODEN DOWEL	8PCS	11		ANCHOR	1PC
4	 ø3*12	SCREW	8PCS	12		FIX BELT	1PC
5		BOLT	4PCS	13		WASHER	2PCS
6		HANDLE	2PCS	14		CAM COVER	8PCS
7		SHELF PIN	8PCS				

TOOL NEEDED:



**PHILIPS SCREWDRIVER REQUIRED
- NOT INCLUDED**

SUGGESTION:



TWO PEOPLE FOR ASSEMBLING



WARNINGS:

1. DO NOT LET ANY SHARP OBJECTS TOUCH OR RUB THE SURFACE OF THE PRODUCT.
2. WHEN ASSEMBLING, DO NOT LET CHILDREN PLAY AROUND THE WORKING AREA.
3. PLEASE CONFIRM ALL PARTS ARE CORRECT BEFORE STARTING THE ASSEMBLY PROCESS.
4. DO NOT TIGHTEN ALL BOLTS AND SCREWS COMPLETELY UNTIL THE ENTIRE UNIT HAS BEEN ASSEMBLED AND SET UP.


1

1
4 PCS $\phi 15 \times 12$

2
4 PCS

3
4 PCS

14
4 PCS



STEP 1:

1. Screw cambolts (2) and insert dowels (3) in panels B & C.
2. Attach panel E to panels B & C and secure with camlocks (1).


2

1
4 PCS $\phi 15 \times 12$

2
4 PCS

3
4 PCS

14
4 PCS



STEP 2:


1. Screw cambolts (2) into panel A.
2. Insert dowels (3) to the tops of panels B & C.
3. Attach panel A to panels B & C and secure with camlocks (1).

3

8



16PCS $\phi 3 \times 12$ D=7



STEP 3:

1. Attach panels F to the back of the cabinet and secure with screws (8) as shown.
2. Insert plastic bar G as shown and finish securing panels F with screws (8).

4

4



ø3*12

8 PCS

5




4 PCS

6



2 PCS



STEP 4:


1. Attach handles (6) to doors H & I with bolts (5).
2. Attach doors H & I to the cabinet with screws (4).

5

7



8 PCS



STEP 5:

1. Insert shelf pins (7) into panels B & C.
2. Rest adjustable shelves D on the shelf pins.

6

10



2 PCS $\phi 4 \times 25$

11



1 PC

12



1 PC

13



2 PCS

