


Contemporary Lighting

PRODUCT NAME: Timbale

ITEM NUMBER: E21146-01PC

Please consult your electrician for hanging fixture and wiring.



The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.


Below is a list of recommended dimmers:

- Lutron MACL-153M
- Lutron DVL-153P
- Lutron SCL-153P
- Leviton IPL06-10Z
- Leviton 6674-POW


Due to inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

Warning! This fixture is supplied with an installed LED driver. These fixtures are dimmable using standard triac dimmer. For best operation we recommend using Lutron CL Dimmers.


IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation



Locate all hardware & components before discarding packaging




1.)




Step.1: Remove mounting bracket from fixture and install to electrical box using screws. Mark where anchors at ends of bracket (A) meet the ceiling. Remove mounting bracket (A) from ceiling. Drill holes using $3/16'' \pm$ drill bit where marked. Install mounting bracket (A) to outlet box using screws and attaching anchors (C) to secure bracket at ends.

2.)



Step.2: Wire fixture to wires in outlet box using wire nuts (D) provided. Copper wire is for Ground.

3.)



Step.3: Install fixture to bracket using finials (E) on the bottom of the canopy to secure. Lights at ends of spiral are adjustable.

Cleaning & Care:

Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

If wires are cut in the process of adjusting the height, please note the ceiling consist of red wire (live) and black wire (ground) that must be separated before re-joining with the driver output wires.

Pendants are wired in parrallel to the driver,as shown below:

