



VINNOVA

Step 4 Parts list 101111-BAF-PC/BG/SN/GM



NO.	PART NAME
1	Screw
2	Index
3	Handle
4	Cover
5	Cartridge lock nut
6	Cartridge
7	Plastic washer
8	Aerator
9	Aerator Shell
10	Body
11	Base
12	O-ring
13	Threadshank
14	Plastic washer
15	Metal washer
16	Lock nut
17	Flexible hose
18	Allen key




SINGLE LEVER LAVATORY FAUCET

The product is CUPC, AB1953, WATERSENSE and NSF certified.


Original certification model code:2010018CP ASME A112.18.1/CSA B125.1




The tools might be applied to the following places:



Step 1 Faucet installation



- 1. Assemble the screw to faucet, position the faucet, base and o-ring on the installation surface.
- 2. Assemble the thread shank, plastic washer and metal washer to faucet. Adjust the position of the faucet, and secure it with the lock nut as photo.




3. Connect the flexible hoses to water supply valve (not included) and copper tubes, and tighten it with adjustable wrench. **DON'T OVER TIGHTEN!**

Caution: make sure connect the hot and cold flexible hose to supply valves correctly.



Warning: The supply valves are not included, please purchase them in plumbshop.



- 1. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute.
- 2. Check all connections at arrows for leaks, re-tighten it if necessary.

Checking and testing



BUT DON'T OVERTIGHTEN

Step 3 Cleaning and care

Daily cleaning and care are required in order to keep the product shining and properly working.

- 1 Clean it with water and dry it with soft cloth.
- 2 Clean the product with gentle liquid or glass cleaner.
- 3 Don't use acid cleaner.
- 4 Don't clean with abrasive material, abrasive paper or knife.