CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from sratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening


Part List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Table Top		1X
В	Foot	-	4X



Item# AMH5745

Product Dimensions:47.25" W x 15.75" D x 20" H




ATTACH YOUR RECEIPT HERE


Serial Number	
-	
Purchase Date	


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 5 minutes.

Step 2







Take all packaging off the accent table.

Step 1

Screw one leg to the table top and gently tighten the legs.

Step 3

Slightly screw four feet through cabinet body to connect with legs. Turn the table up to right side, adjust the legs and feet to make it stable.