tala

Installation Guide NINE PENDANT

Thoughtful lighting, responsibly designed in London.

Thank you for making the switch to Tala. Discover the full Tala family at us.tala.co.uk

BEFORE STARTING

We recommend the installation of our canopy and pendants is performed by a qualified electrician. Please read the instructions thoroughly before commencing work and keep them for future reference. Please take extreme care when carrying out these instructions.

IMPORTANT

This light fitting must be connected to the earth supply. If your lighting circuit does not have an earth, ask a qualified electrician to provide an earth facility. This light fitting is suitable for indoor use only. This fitting operates on 120V mains voltage. For a list of recommended dimmers to pair with this light fitting, please visit our website.

WARNING

You must switch off electricity supply at the mains during installation and maintenance. We strongly recommend that you withdraw the fuse or switch off the circuit breaker whilst work is in progress. Do not only turn off the wall switch. All fittings must be installed in accordance with current NFPA 70, National Electrical Code (NEC).

RECOMMENDED EQUIPMENT

- Small flat head screwdriver
- Wire strippers
- Insulation tape

Further equipment may be required for fixing to your ceiling

SKU - CP-WHT-LRG-OP-01-US

SKU - CP-WHT-LRG-WP-01-US

SKU - CP-BLK-LRG-GP-01-US



FOR INDOOR USE ONLY





IP20

110-120V

Nine Pendant - Provided Components









STEP 2B

Re-assemble the plate in the same order and fasten it securely with nuts (1) and washers (2).

Replace the Cord grips \bigcirc and secure with the nuts and washers.

Tighten all firmly with a spanner/ wrench.







STEP 4

Thread all nine pendant cables (F) through ceiling plate cord grips (C)

STEP 5

Pull cables through to your desired length. See end of this guide for our recommended lengths and distance between bulbs.

Using a flat head screwdriver, tighten set screws C to secure them.

STEP 6

Cut off excess cable and strip wires to expose the copper core. Maintain all double insulation.





STEP 8

 ${\rm Lift}\, \textcircled{B}{\rm to}\, {\rm sit}\, {\rm flush}\, {\rm with}\, \textcircled{A}.$

Make sure the pins $\fbox{1}$ are located at the opening of the bayonet fitting $\fbox{2}$

STEP 9

Rotate plate (B) anti-clockwise until the pin is locked into the (1) bayonette mechanism (2) .

Secure plate (B) in place using bolt (G)

There will be a small shadow gap between the canopy and the ceiling.



PENDANTS DISPLAY GUIDE

MINIMUM CORD LENGTH (A)

For all bulbs shortest recommended cord length is 14 in

DISTANCE BETWEEN PENDANTS (B)

Recommended minimum distance between pendant, dependant on bulb style, are as follows:

Voronoi I - 6 in Voronoi II - 8 in Voronoi III - 14 in Sphere IV - 6 in All other bulbs - 4 in









WARRANTY AND AFTER-CARE

This product has a two-year warranty. If there appears to be a functional defect with the product during this time, please contact our team at customerservice@tala.co.uk.

Please note, the flexible cable attached to this luminaire cannot be replaced; if the cable is damaged, recycle the luminaire and seek a replacement.

Join the Community

Instagram: @tala | Facebook: talaHQ | Pinterest: TalaLED | Tag: lighttoliveby Tala Energy Ltd. 25B Vyner Street, London, E2 9DG | hello@tala.co.uk Tala North America, Inc. 2 Research Place, Suite 300, Rockville, MD 20850