


DINING CHAIR UC-4




HARDWARE:



PARTS LIST





Put chair back on a clean flat surface.


Place seat pad against chair back as shown in diagram.

Secure center holes of the seat pad to chair back by using SHORTER

SCREW (D) with Washer (#A,B).

DO NOT FULLY TIGHTEN.

First HAND tighten then tightened using key up-to 60-80% only at this stage.




Secure both corner holes of the seat pad to the chair back by using

LONGER SCREWS (F) with washers (#A,B).

DO NOT FULLY TIGHTEN. First HAND tighten All 4 screws TOGETHER at the same time.

Tightened up-to 60-80% using key only at this stage.



Align front legs in the seat pad as shown in the diagram.


Firm pressure is required to push the legs. use parts C,E,A,B,to secure Again


Secure both corner holes of the seat pad to the chair back by using screws MEDIUM SCREWS (E) with washers (#A,B).

DO NOT FULLY TIGHTEN.

First HAND tighten All 4 screws TOGETHER at the same time.

Tightened up-to 60-80% using key only at this stage.





TROUBLESHOOT

One screw is in and other screw does not go in. Or Holes are not align.

- 1. Make sure to use 4 Medium screws (E) in Front Corner, 1 Shorter screw (D) in Back Center and longer screw (F) in the Corner Back.
- 2. Loosen the screw and then First HAND tightened All screws TOGETHER at the same time. then tightened to 60-80% at this stage only using key.
- 3. If both above steps are correct, please use Key to secure screws. It might be little stiff.

Chair Legs are not level or shorter legs.

If the screws are fully tightened. Loosen screws up-to 60%. Put chair in the upright position and SIT ON THE CHAIR to press downwards on the seat pad ensuring that all 4 feet touch the ground and are leveled. Tightened all one by one.

